

Installation Guide


Please contact AFA first

For Installation Help, Missing or Replacement Parts

Phone: (949)477-4195 Fax: (949)477-4196


Email: customer.service@afastainless.com

AFA USA LLC



HELPFUL TOOLS


For safety and ease of faucet replacement, AFA recommends the use of these helpful tools.




STAINLESS STEEL DROP-IN SINKS


INCLUDES ALL AFA AFA DROP-IN SINKS WITH CHANNEL MOUNTING SYSTEM

AFAStainless







Position sink upside down on counter and trace outline.




Draw cut line 1/4" inside the sink outline.



Drill pilot holes on cut line.




Carefully cut counter hole following inside of the cut line. Remove counter material.




Install faucet and drain fittings and accessories according to manufacturer's instructions.


AFAStainless




Ready installation clip by partially threading screws into clip.




Apply a bead of caulk 1/8"-1/4" away from edge of counter cutout.




Center sink within counter opening. Apply even pressure to all sides. Wipe away any excess caulkon counter.



On underside of counter slide clips onto mounting rail centering brackets along each side, 12 brackets recommended.



Tighten installation screws in order as shown above.



Connect faucet and drain fittings.

